



STARTER

FAMILY CODE: **31654**

The starter is an essential component in starting the vehicle. It starts the engine combustion.



NON-EMITTED CO₂*: **12,1 kg**



MATERIAL SAVINGS*: **3,49 kg**

*Source: Life-Cycle Assessment (LCA) Europe.
Based on a European study Material savings and non-emitted CO₂ on average compared with the new equivalent MOPAR genuine part. Values are given for information only, corresponding to the main seller of the similar products and determined according to a methodology approved by an independent company (Sphera methodology).



REMANUFACTURING STEPS

- Full cleaning
- Systematic replacement of moving parts: drive sprockets, bearings, seals, rings, etc.
- Durability and output power test, for Stop and Start starters (STT)



MAINTENANCE & REPAIR GUIDELINES

The starter must be replaced when:

- The control indicator lamps are on and there is no response to turning the ignition key

EE SA NA

