



BRAKE CALIPER

FAMILY CODE: 30594

The brake caliper supports the brake pads. Its hydraulic piston applies the brake pads to the disc to ensure that braking occurs.

> NON-EMITTED CO₂*: *under investigation*

MATERIAL SAVINGS*: *under investigation*



- Full cleaning, galvanized and/or repainted.
- Systematic replacement of moving parts: seals, dust cover, bleed screws, etc.
- Reuse the majority of parts after structural analysis
- Recondition the caliper
- Check dimensional tolerance and measurement of all components
- Pre-fill the brake caliper (brake fluid)




The brake caliper must be replaced when:

• The caliper piston has seized

• The brake fluid leaks



- Opposite caliper
- Brake hoses
- Discs
- Pads
- Brake fluid



*Source: Life-Cycle Assessment (LCA) Europe.

Based on a European study Material savings and non-emitted CO_2 on average compared with the new equivalent MOPAR genuine part. Values are given for information only, corresponding to the main seller of the similar products and determined according to a methodology approved by an independent company (Sphera methodology).