



CLUTCH KIT

FAMILY CODE: **20184**

The clutch kit is used to engage gears. It is the intermediary part between the engine and the gearbox.



NON-EMITTED CO₂*: 14,8 kg



MATERIAL SAVINGS*: 5,34 kg

*Source: Life-Cycle Assessment (LCA) Europe. Based on a European study Material savings and non-emitted CO₂ on average compared with the new equivalent MOPAR genuine part. Values are given for information only, corresponding to the main seller of the similar products and determined according to a methodology approved by an independent company (Sphera methodology).



REMANUFACTURING STEPS

- Full cleaning and paintwork for perfect protection against rust
- Systematic replacement of moving parts: friction disc, bearings, etc.
- Check dimensional tolerance and measurement of all components



MAINTENANCE & REPAIR GUIDELINES

The clutch kit must be replaced when:

- The clutch pedal is stiff
- There is hesitation when starting
- The clutch slips
- Changing gear is difficult



ADDITIONAL CHECKPOINTS

- Gearbox oil
- Clutch master and slave cylinders
- Steering rods
- Driveshafts

