



CD CHANGER

FAMILY CODE: 85162

The CD changer stores and plays multiple discs.







- Clean the unit and connectors
- Read the list of faults to identify failures
- Preventive replacement of all worn and fragile components to ensure long-term durability
- Full operational test on a simulation bench
- Fitting on the vehicle, identical to the genuine part



The CD changer must be replaced when:

- The CD function does not start up
- The CD rack is jammed inside the reader



Speakers

