



GEARBOX HYDRAULIC BLOCK

FAMILY CODE: 30874

The gearbox hydraulic block is a central component of the automatic gearbox. It regulates the oil pressure and flow. This component allows the gears to be changed and engaged.





• Dismantle, clean and change the valves




The gearbox hydraulic block must be replaced when:

- The gears no longer engage or do not engage correctly
- The gearbox temperature is abnormally high



Gearbox oil

• Torque converter



*Source: Life-Cycle Assessment (LCA) Europe.

Based on a European study Material savings and non-emitted CO_2 on average compared with the new equivalent MOPAR genuine part. Values are given for information only, corresponding to the main seller of the similar products and determined according to a methodology approved by an independent company (Sphera methodology).