



MANUAL TRANSMISSION

FAMILY CODE: **30864**

The manual gearbox increases the power between the engine and the wheels. More specifically, the gearbox coordinates the rotational speed of these two components, so that the wheels turn at the desired speed.



NON-EMITTED CO₂*: 69,2 kg



MATERIAL SAVINGS*: 29,4 kg

*Source: Life-Cycle Assessment (LCA) Europe.
Based on a European study Material savings and non-emitted CO₂ on average compared with the new equivalent MOPAR genuine part. Values are given for information only, corresponding to the main seller of the similar products and determined according to a methodology approved by an independent company (Sphera methodology).



REMANUFACTURING STEPS

- Full dismantling of components
- Component checks (dimensions and functions)
- Clean and recondition all parts to their original condition
- Replace damaged or worn parts with new components



MAINTENANCE & REPAIR GUIDELINES

Must be replaced when:

- There is an oil leak
- The gearbox makes a noise in neutral
- It is difficult to change gear or a gear does not engage
- The gear jumps while driving



ADDITIONAL CHECKPOINTS

- Driveshafts
- Clutch and engine flywheel
- Clutch control
- Clutch fluid

EE SA NA

